

FREIHAFEN

*Einfach **genießt** das Leben*



ELECTRIC CHOPPER

OPERATION MANUAL

The use of any electrical appliance requires the following of common-sense safety rules.

Location: For Indoor use only.

Cable Management

- The cable should reach without straining the connections.
- Do not let the cable hang over the edge of a worktop where a child could reach it.
- Do not let the cable run across an open space e.g. between a low socket and table.
- Do not let the cable run across a cooker or toaster or other hot area which might damage it.

Your Safety

- Unplug before cleaning or removing parts.
- Do not touch moving parts. Keep hands, hair, clothing as well as utensils away from the hand blender blades.
- Don't let rotating blades touch the cable.
- TAKE CARE WHEN HANDLING METAL BLADES AS THEY ARE VERY SHARP.
- Don't clean the blades under running water while they are in position.
- Make sure the blender is switched off before connecting to or disconnecting from power.

Children

This appliance is not intended to be used by Children.

Other Safety Considerations

- To protect against fire, electric shock and personal injury do not immerse cord, plug or blender in water or other liquid.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- Do not use accessories not recommended by the manufacturer as there is the danger of fire, electric shock or personal injury.
- Do not place on or near a hot gas or electric burner or in a heated oven.
- Unplug from outlet when not in use.

Your Chopper is designed to help you chop meat and vegetables with minimal effort.

UNPACKING YOUR CHOPPER

Carefully unpack your Chopper, as blades are very sharp.



IMPORTANT NOTE:

Please use the whole hand, not just one finger. The electric multi-shredder can only be started when the electronic part and the glass bowl are pressed down completely. During use, please place your entire palm on the housing and press the palm of your hand to the appropriate level.




CAUTION:

NEVER USE YOUR APPLIANCE IN A BOWL OR SAUCEPAN WHILE COOKING.

SPEED SWITCH:

The appliance is designed to process with different speeds. You can turn the speed switch in order to adjust for your needs. (see processing guide)



Cleaning

Before cleaning and maintenance, switch the appliance off and unplug it.

1. Remove the chopper blade.
2. Clean the chopper attachment and bowl in warm soapy water and dry thoroughly.
3. Clean the main housing with a damp cloth and dry thoroughly.

Trouble Shooting

Check if the plug is properly connected?

Is the plug itself or the socket faulty? Check this by plugging in another appliance. Check the following for a possible cause.

- Appliance gets very hot after max speed operation.
Chopper is running hot. Let the appliance cool down to room temperature.
- Appliance not starting.

The removable chopper attachment has not been fitted correctly. Unscrew the attachment and replace as described in 'assembly'.

Technical Data

Model: HR-618

Power Supply: AC 220-240V 50/60Hz

Output: 300W

Capacity of the glass bowl: 1.5L

Safety Class: II

How to operate your chopper attachment

The chopper is perfectly suited for chopping meat, cheese, onions, herbs, garlic, carrots, prunes etc.

NOTE

1. do not cut extremely hard foods such as nutmeg, coffee beans and cereals. Do not cut hard objects such as ice cubes or bones. This will damage the knife. Do not stir food such as flour, bread, etc. They are sticky in the presence of water and will affect the operation of the motor. If you fill in too few ingredients, the motor will run at idle.
2. the continuous processing time of the product must not exceed 30 seconds, and the product must rest for 2 minutes after it has been worked continuously for 30 seconds. The cycle is 2 minutes at 30 second intervals and the product must rest for 15 minutes after 3 continuous cycles.
3. please do not use water or food higher than 70 °C.

Before chopping

Prepare meat, cheese, onions, garlic, carrots, chills (see processing guide)


Remove stalks from herbs, remove nutshell from nuts

Remove bones, tendons and gristle from meat.


For best results, please refer to the settings recommended in the processing guide.

Chopping

1. Place the blade on the center pin of the chopper bowl. Always make sure the anti-slip base is attached to the bowl. (step 1).
2. Place the food in the chopper bowl (step 2).
3. Put the bowl cover on the chopper bowl (step 3).
4. Insert the main body into the bowl cover until it locks (step 4).
5. Press the switch to operate the chopper. During processing, hold the main body with your hand.
6. After use, first remove the main body, then the bowl cover.
7. Carefully take out the blade.
8. Remove the processed food from the chopper bowl.




STEP 01



STEP 02



STEP 03




STEP 04

Processing guide

Food	Weight	Time	Speed
pork	≤500g(20*20*20mm)	≤30s	high speed
beef	≤500g(20*20*20mm)	≤30s	high speed
garlic	300g	15s	low speed
chili	300g	15s	low speed
carrot	300g(20*20*20mm)	15s	low speed
celery	300g	15s	low speed

FREIHAFEN

Simply enjoying life



Email

Service@Freihafen.shop

Website

www.Freihafen.shop

Phone

0049-040-69638976-8

EU **Vertreter**

STEO GmbH, Ludwig-Erhard-Straße 18, D-20459,
Hamburg (Adresse ist nicht für Retourware)